

Alpine Scythe Assembly instructions



1. Loosen the clamp using a flat screwdriver to remove the 'key' supplied. (keep this key as it can be used from this point on to remove/attach the blade) Then slide the loose clamp back up the handle.

2. Line up the 'lug' on the end of the blade with the groove in the handle, and then slide the clamp over the blade attachment, making sure the 2 screws on the clamp are against the back of the blade and not the aluminium shaft.

3. Tighten the 2 screws fully against the back of the blade.

